

Installation Tools

1. Job preparation

- tape measures (50 m and 5 m)
- chalk line
- scissors
- claw hammer
- stiff bristle brooms
- squeegee

2. Cleaning the Firestone Geomembrane

- clean cotton rags
- cleaning agent - Splice Wash (in petrol can)

3. Mechanical fixation

- drilling machine with key
- drill bits (masonry and steel)
- hack-saw with blades
- screw-driver
- caulking gun
- tin snip

4. Field seams

- QuickScrubber tool (pad + handle)
- small plastic bucket
- marker (white)
- roller - 50 mm width (silicon rubber)

5. Adhesion of the Firestone Geomembrane

- brushes (solvent resistant, short hair, 100 mm width)
- paint rollers (solvent resistant, short hair, 225 mm width)
- hot air gun
- roller - 50 mm width (silicon rubber)

6. Additional

- electrical leads
- rubber gloves